


Shrubber

Example 1

Install shrubber base (DSHB) or (DSHT) directly into supply line



Example 2

Add 1/4" transfer barb (14TB) and 1/4" tubing (14100) to place shrubber (DSHS) at base of plant

- Adjustable head
- Flow 0-13 GPH (gallons per hour)
- Take apart style for cleaning
- Low angle strand watering pattern
- 10-50 PSI range (pounds per square inch)

Adjustable Shrubber is available in:

1/4" barb base (DSHB), on 5" stake full circle (DSHS), on 5" stake half circle (DSHS180) and 10/32 threaded base (DSHT)

Use the shrubber to water bushes, containers and shrubs.

Flow vs. Pressure

Flow is the output of water measured in GPH (gallons per hour) or GPM (gallons per minute) and pressure is the force behind the flow measured in PSI (pounds per square inch).